

# MOTION LEARNING AND MONITORING

---


Powered by a NeuroMem network

On Arduino platform

General Vision Technical Brief




# Assembly

- Arduino microcontroller board with at least 3 KB of dynamic memory
- NeuroShield featuring
  - InvenSense Accel/Gyro
  - 576 NeuroMem neurons
- Optional set of spacers






# Installation

1. Download the latest Arduino IDE (<https://www.arduino.cc/en/Main/Software>)
2. Under the Tools\Board menu, select your board model.
  - If not in the list, select Board Manager and install its driver
3. Load the File\Examples\Basic\Blink script
4. Upload the script to your board
5. Verify that the LED is blinking



# Running the demo

1. Load the NeuroShield\_MotionRecoDemo
2. Upload the script to the Arduino
3. Verify that the upload is successful.
  - If not, go to troubleshooting slide
4. Open the serial Monitor
5. Follow the instructions on the screen.
  - If the window is blank and frozen, go to the Troubleshooting slide



# Academic training case

- Move the board up and down
- Type 1+Enter to teach vertical motion
- Move the board left and right
- Type 2+Enter to teach horizontal motion
- Stop moving
- Type o + Enter to teach “No motion”

```
COM3 (Arduino/Genuino 101)

NeuroMem_Smart device is initialized!
Neuron capacity = 576
NN Maxif = 32768

IMU connection successful!

Calibration...Make sure your board is stable.  Type enter when ready
Calibration terminated

Type a command + Enter
h = help
s = stop
1 to 9 = start learning motion type 1 to 9
0 = incorrect recognition
r = recognize
t = transmit sensor data
v = show vector
n = show neurons
c = show configuration
f = clear the knowledge


☒ Autoscroll
```




# Continuous recognition

- Report 1 for up-down motion
- Report 2 for left-right motion
- Report Unknown for anything else

```
COM3 (Arduino/Genuino 101)
No known motion
Motion category #1
No known motion
Motion category #1
No known motion
Motion category #2
No known motion
Motion category #2
No known motion
Motion category #2
```



# Script workflow



# About the feature extraction

// This example is very academic and assemble a simple sequence pattern which should be more  
// sophisticated to address a real-life problem such as real-time sampling rate and calibration  
// adequate for the type of motion being studied.  
// More advanced feature extractions can include waveform profiles, distribution of peaks and zero  
crossing, etc.

NeuroShield\_MotionRecoDemo

```
for (int j=0; j<sampleNbr; j++)  
{  
    getSensorData();  
    vector[(j*channelNbr)]= (int) (ax);  
    vector[(j*channelNbr)+1]= (int) (ay);  
    vector[(j*channelNbr)+2]= (int) (az);  
    vector[(j*channelNbr)+3]= (int) (gx);  
    vector[(j*channelNbr)+4]= (int) (gy);  
    vector[(j*channelNbr)+5]= (int) (gz);  
}
```

} Collect N consecutive measurements of ax,  
ay, az, gx, gy, gz and append to a feature  
vector







# Example using 1 feature

Quick & simple  
sampling

WARNING:  
combines data with  
different dimensions,  
different calibration  
and normalization



# Examples using 2 features




# What is next?

- Improve the calibration routine
- Extract more advanced feature(s) depending on the application
- Improve UI to better synchronize the teaching instruction to the real-time motion
- And more....



# Typical signal monitoring workflow



# Troubleshooting

- Script does not load properly
  - Verify the selected platform and COM port under Tools menu
  - Use the board's external power supply instead of the USB power
  - Unplug all shields for the duration of the upload
- Serial monitor is blank and frozen
  - Verify the selected baud rate
  - Close the window
  - Unplug / Replug the Arduino board
  - Wait a few seconds and re-open the serial monitor

